**ARBORTRONICS Inc.** 1520 Lodestar Road, Unit 20, Downsview, Ontario M3J 3C1

Downsview, Ontario M3J 3C1 Tel.: (416) 638-6112 Fax: (416) 638-0007 E-mail: <u>sales@arbortronics.com</u> Web: <u>www.Arbortronics.com</u>

## **Dual Pulse Timer 11**

# Model DPT11

#### DESCRIPTION

The Dual Pulse Timer 11 (DPT11) has one main power cable, one input, two power outputs, two user settable timers and accumulator triggers. The DPT11 monitors flow meters/sensors that product a pulse signals and use these signals to govern its outputs. The outputs may be used to control metering pumps, valves or other actuators in a large variety of applications.

#### **OPERATION**

The DPT11 monitors the sensors that are attached and accumulates the pulses until the number of pulses is equal to the setting of the accumulator trigger. The outputs turn on for user defined periods.

There are two main modes of operation provided, they are the **Parallel mode** and the **Serial mode**. In **Parallel mode**, the input pulses are counted in two accumulators with independent settings. When each accumulator reaches its preset value, the corresponding power output is activated, regardless of the other accumulator/output state. Once the power output is activated, the cycle repeats. In **Serial mode** the input pulses are counted in only in accumulator 1. When the preset number of pulses are reached, output 1 is activated for the time set on timer 1. After output 1 deactivates, output 2 is activated for the period of time set on timer 2. Once output 2 is activated, the cycle repeats. A manually activated self-test procedure is built in.

### **INDICATORS**

- "POWER" Unit is connected to power.
- "INPUT" Pulse input has been received.
- "OUT 1" Power output 1 is active
- "OUT 2" Power output 2 is active
- "OVERFLOW 1" Output 1 could not complete it activation period due to a cycle reset caused by the accumulator reaching its preset value.
- "OVERFLOW 2" Output 2 could not complete it activation period due to a cycle reset caused by the accumulator reaching its preset value.

**Note:** The overflow situation occurs when the timer is set for a long period, while the accumulator is set to a point, which is reached, in a shorter time than the timer period. This situation should be avoided.

#### **SPECIFICATION**

- Power
- Accumulator Range
- Timer Range
- Enclosure
- Max. Input Frequency
- Input Debouncing
- Relay Contact Rating
- Sensor Power

- 115VAC Nominal
- 1 to 1270 Counts
  - 1 to 1270 Seconds
- Glass-filled polycarbonate, 7" x 5" x 3"
- 400 Hz (pulses/second)
- 1 ms
- 5A resistive at 115VAC
- 25mA at 12VDC nominal